
Whirlpool

OVEN PARTS


30" BUILT-IN ELECTRIC OVEN SELF CLEAN




OVEN PARTS


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1 3	8303647 8303870 8301758 8303946 3191638 9759133 8301928 8302908 8302909 8302911 8303213 8302907 8302910 8302912 8303214 4455605	Literature Parts Installation Instructions Use & Care Guide (Oven) Tech Sheet (Oven) Installation/ Undercounter Safer Cooking Tips English French Instructions Microwave Trim Kit Trim, Side (Right Hand) Black White Biscuit Stainless (Left Hand) Black White	4 5 7 8 9 10 11 12 13 14 15 16 17 18 19 21 22 23 25 26 27	4448520 3400832 3400805 8303099 4452490 4452158 4452165 4452368 4452337 9759060 4455382 4449809 4449040 4452152 4451478 8303115 8303116 4448444 9759525 4449154 4455641	Bumper, Door Screw Black Zinc Top Chassis Spacer, Foam Tube, Vent Lens, Light Oven Light Assy Bulb, Light Insulation, Bottom Vent Frame, Front Gasket, Door Screw Screw Bracket, Mounting Support, Insulation Rail, Side Right Side Left Side Grommet Latch, Motorized	29 33 37 43 49 50 53 55	4455636 9760677 9759243 9759713 4448933 4451747 4449845 8302947 8302948 8302949 8302950 FOLLOW NOT ILL	Sensor Deflector, Vent Thermostat (TOD) (Temp.) SPST Base, Chassis Retainer, Gasket Cover, Back Support, Bracket Trim, Bottom Black White


OVEN DOOR PARTS



INTERNAL OVEN PARTS









No.	No.	DESCRIPTION				
2	4456103	Element, Broil				
	4449154	Screw				
6	4448717	Rack, Oven				
7	4452153	Element, Bake				
	4449154					

CONTROL PANEL PARTS



Illus. No.	Part No.	DESCRIPTION
1		Control Panel Assy.
,	8302848	
	8302849	
	8302850	Biscuit
2		Membrane Switch
	8304242	Black
	8304243	White
	8304244	Biscuit
3	8303885	Microcomputer
4	8304161	Bracket, Control
5	8302877	Cover. Stainless

TOP VENTING PARTS



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1 2 3 4 5 6 7	4455178 4457289 4451758	Block, Foam Elbow, Vent-Bottom Screw	8 9 11 13	3400080 4450038 4449868 8303497	Screw Block, Terminal	14 15 16 17 18 19	4450551 4448664 4450554	Left Back, Control Cover, Top Rear

OPTIONAL PARTS

For Models:RBS305PRB00, RBS305PRQ00, RBS305PRT00, RBS305PRS00 (Black) (Designer White) (Biscuit) (S.Steel)

Illus. **Part Part Part** Illus. Illus. No. **DESCRIPTION** No. **DESCRIPTION** No. No. No. No. **DESCRIPTION** SPLICING WIRES--25FT. **WIRING HARNESS PARTS** PAINT, TOUCH-UP (1/2oz.) **LENGTH** 8301400 Harness, Wire 72017 White (Main) 261869 Cord Brown 242828 Wire (12 Ga. 4450952 Conduit 72032 Black 150 c Black) 4449809 Screw 242820 Wire (14 Ga. 112432 Nut PAINT, SPRAY 150 c Black) 4450800 Screw, Ground 4451761 Support, Wiring 4454842 Tie, Cable 242821 Wire (14 Ga. 350930 White 150 c Blue) 261900 Citrine White 242822 Wire (14 Ga. 830864 Black 150 c Brown) **Miscellaneous** 242830 Wire (14 Ga. **ADHESIVE** 200 c Brown) 4396923 Broiler Pan Assy. 242823 Wire (14 Ga. 814381 Pin Hinge Kit 591014 Adhesive 150 c Green) 4448950 Screw, Install (4) Loctite (1/3 oz.) 242824 Wire (14 Ga. 482338 Sealer, Silastic 150 c Orange) (3 oz.) 242825 Wire (14 Ga. 150 c Red) 242831 Wire (14 Ga. 200 c Red) 242827 Wire (14 Ga. 150 c Yellow)